



## ABSTRACT

The PWR-634EVM evaluation module uses either the TPS544C20 or TPS544B20 devices. The TPS544C20 and TPS544B20 are highly integrated synchronous buck converters that are designed for up to 30-A or 20-A current output, respectively.

## Table of Contents

<b>1 Description</b> .....	2
1.1 Typical Applications.....	2
1.2 Features.....	2
<b>2 Electrical Performance Specifications</b> .....	3
<b>3 Schematic</b> .....	4
<b>4 Test Setup</b> .....	5
4.1 Test and Configuration Software.....	5
4.2 Test Equipment.....	6
4.3 The PWR-634EVM.....	7
4.4 Test Set up and USB Interface Adapter.....	8
4.5 List of Test Points.....	9
<b>5 EVM Configuration Using the Fusion GUI</b> .....	10
5.1 Configuration Procedure.....	10
<b>6 Test Procedure</b> .....	11
6.1 Line/Load Regulation and Efficiency Measurement Procedure.....	11
6.2 Efficiency.....	11
6.3 Equipment Shutdown.....	11
<b>7 Performance Data and Typical Characteristic Curves</b> .....	12
7.1 Efficiency.....	12
7.2 Load Regulation.....	12
7.3 Transient Response.....	13
7.4 Output Ripple.....	14
<b>8 Screen Shots</b> .....	17
8.1 Fusion GUI Screen Shots.....	17
<b>9 EVM Assembly Drawing and PCB Layout</b> .....	31
<b>10 List of Materials</b> .....	35
<b>11 Revision History</b> .....	37

## 1 Description

The PWR-634EVM is designed as a single output DC-DC converter that demonstrates either the TPS544C20 or the TPS544B20 in a typical low-voltage application while providing a number of test points to evaluate the performance. It uses a nominal 12-V input bus to produce a regulated 1.0-V output at up to either 30-A or 20-A of load current, depending on the device installed.

### 1.1 Typical Applications

- High-Density Power Solutions
- Communications equipment
- Servers and Computing equipment
- Smart Power Systems

### 1.2 Features


- Regulated 1.0-V output up to 30-ADC, steady-state output current
- Output is marginable and trimmable via the PMBus interface.
  - Programmable: UVLO, Soft Start, and Enable via the PMBus interface
  - Programmable overcurrent warning and fault limits and programmable response to faults via the PMBus interface
  - Programmable overvoltage warning and fault limit and programmable response to faults via the PMBus interface
  - Programmable high- and low-output margin voltages with a maximum range of 10%, –20% of nominal output voltage
- Convenient test points for probing critical waveforms

## 2 Electrical Performance Specifications

Table 2-1. PWR-634EVM Electrical Performance Specifications

PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNITS
<b>Input Characteristics</b>					
Voltage range	$V_{IN}$	8	12	14	V
Maximum input current	$V_{IN} = 8 \text{ V}$ , $I_O = 30 \text{ A}$			5	A
No load input current	$V_{IN} = 14 \text{ V}$ , $I_O = 0 \text{ A}$		100		mA
<b>Output Characteristics</b>					
$V_{OUT}$	Output voltage	Output current = 10 A		1.0	V
$I_{OUT}$	Output load current	$I_{OUT\_min}$ to $I_{OUT\_max}$		0	30
Output voltage regulation	Line regulation: Input voltage = 8 V to 14 V		0.5%		
	Load regulation: Output current = 0 A to $I_{OUT\_max}$		0.5%		
$V_{OUT}$	Output voltage ripple	$V_{IN} = 12 \text{ V}$ , $I_{OUT} = 20 \text{ A}$		30	mVpp
$V_{OUT}$	Output overcurrent		20		A
<b>Systems Characteristics</b>					
Switching frequency	$F_{SW}$	500		kHz	
$V_{OUT}$	Peak efficiency	$V_{IN} = 8 \text{ V}$ , $I_O = 10 \text{ A}$ , $F_{SW} = 300 \text{ kHz}$		92%	
$V_{OUT}$	Full-load efficiency	$V_{IN} = 8 \text{ V}$ , $I_O = 10 \text{ A}$ , $F_{SW} = 300 \text{ kHz}$		90%	
Operating temperature	$T_{oper}$	105		°C	

### 3 Schematic



**Figure 3-1. PWR-634EVM Schematic**

## 4 Test Setup

### 4.1 Test and Configuration Software

To change any of the default configuration parameters on the EVM, it is necessary to obtain the TI Fusion Digital Power Designer software. This can be downloaded from the TI website.

#### 4.1.1 Description

The Fusion Digital Power Designer is the graphical user interface (GUI) used to configure and monitor the Texas Instruments TPS544B20 or TPS544C20 power converter installed on this evaluation module. The application uses the PMBus protocol to communicate with the controller over serial bus by way of a TI USB adapter (see [Figure 4-2](#)).

#### 4.1.2 Features

Some of the tasks you can perform with the GUI include:

- Turn on or off the power supply output, either through the hardware control line or the PMBus operation command.
- Monitor real-time data. Items such as input voltage, output voltage, output current, temperature, and warnings and faults are continuously monitored and displayed by the GUI.
- Configure common operating characteristics such as VOUT trim and margin, UVLO, soft-start time, warning and fault thresholds, fault response, and ON/OFF.

This software is available for download at [http://www.ti.com/tool/fusion\\_digital\\_power\\_designer](http://www.ti.com/tool/fusion_digital_power_designer)

## 4.2 Test Equipment

**Voltage Source:** The input voltage source VIN must be a 0-V to 14-V variable dc source capable of supplying at least 5 Adc. Connect VIN to J2 [Figure 4-1](#).

**Multimeters:** It is recommended to use two separate multimeters [Figure 4-1](#). One meter is used to measure Vin and one to measure Vout.

**Output Load:** A variable electronic load is recommended for testing [Figure 4-1](#). It must be capable of 30 A at voltages as low as 0.9 V.

**Oscilloscope:** An oscilloscope is recommended for measuring output noise and ripple. Output ripple must be measured using a Tip-and-Barrel method or better as shown in [Figure 4-3](#). The scope must be adjusted to 20-MHz bandwidth, ac coupling at 50 mV/division, and must be set to 1- $\mu$ s/division.

**Fan:** During prolonged operation at high loads, it may be necessary to provide forced air cooling with a small fan aimed at the EVM. Temperature of the devices on the EVM must be maintained below 105°C.

**USB-to-GPIO Interface Adapter:** A communications adapter is required between the EVM and the host computer. This EVM was designed to use the Texas Instruments USB-to-GPIO Adapter (see [Figure 4-2](#)). This adapter can be purchased at <http://www.ti.com/tool/usb-to-gpio>.

**Recommended Wire Gauge:** The voltage drop in the load wires must be kept as low as possible in order to keep the working voltage at the load within its operating range. See the following table for recommended wire gauge and length to achieve a voltage drop of no more than 0.2 V at the maximum 30-A load.

AWG GAUGE	$\Omega$ PER FOOT ( $\Omega$ )	LOAD WIRES COMBINED LENGTH (Ft)	EACH WIRE LENGTH (Ft)
12	1.59E-3	6.30	3.15
14	2.53E-3	3.96	1.98
16	4.02E-3	2.49	1.25
18	6.39E-3	1.57	0.78

As an example, if AWG 12 wire is used, no more than 3.15 feet of wire must be used between the EVM and the load.

#### 4.3 The PWR-634EVM



Figure 4-1. PWR-634EVM Overview

#### 4.4 Test Set up and USB Interface Adapter





Figure 4-2. Complete Test Setup Including Texas Instruments USB-to-GPIO Adapter



**Tip and Barrel  $V_{OUT}$  Ripple  
Measurement**

Figure 4-3. Tip and Barrel Measurement

## 4.5 List of Test Points

**Table 4-1. The Function of Each Test Point**

TEST POINT	TYPE	NAME	DESCRIPTION
TP1	T-H loop	PGOOD	Power good signal for $V_{OUT}$ .
TP2	T-H loop	ADJ	Output voltage adjust
TP3	T-H loop	SMBALERT	SMB alert signal
TP4	T-H loop	BPEXT	Bypass connect
TP5	T-H loop	$V_{OUT}$ + Sense	
TP6	T-H loop	$V_{OUT}$ – Sense	
TP7	T-H loop	$V_{OUT}$ +	
TP8	T-H loop	$V_{IN}$ +	
TP9	T-H loop	$V_{IN}$ –	
TP10	T-H loop	GND	
TP11	T-H loop	$V_{OUT}$ –	
TP12	T-H loop	CNTL	Control signal

## 5 EVM Configuration Using the Fusion GUI

The TPS544B20 or TPS544C20 installed on this EVM leave the factory pre-configured. See [Table 5-1](#) for a short list of key factory configuration parameters as obtained from the configuration file.

**Table 5-1. Key Factory Configuration Parameters**

ADDRESS HEX	ADDRESS DEC	PART ID			
0x1B	27	TPS544x20			
<b>GENERAL</b>					
CMD ID WITH PHASE	CMD CODE HEX	ENCODED HEX	DECODED	NUMERIC	COMMENTS
VIN_OFF	0x36	0xF014	5.00 V	5	Turn OFF voltage
VIN_ON	0x35	0xF01C	7.00 V	7	Turn ON voltage
<b>TPS544B20</b>					
IOUT_CAL_GAIN	0x38	0x8821	1.0071 mΩ	1.0071	DCR of output inductor
IOUT_CAL_OFFSET	0x39	0xE000	0.0000 A	0	Current offset for GUI readout
IOUT_OC_FAULT_LIMIT	0x46	0xF83C	30.0 A	30	OC fault level
IOUT_OC_FAULT_RESPONSE	0x47	0x3C	Restart continuously		Response to OC fault
IOUT_OC_WARN_LIMIT	0x4A	0xF832	25.0 A	25	OC warning level
MFR_04 (VREF_TRIM)	0xD4	0x0000	0.000 V	0	Trim voltage
ON_OFF_CONFIG	0x02	0x02	Mode: always converting		Control signal and operation command not required
OPERATION	0x01	0x00	Unit: immediate off; margin: none		Response to turn OFF trigger
OT_FAULT_LIMIT	0x4F	0x007D	125°C	125	OT fault level
OT_WARN_LIMIT	0x51	0x0064	100°C	100	OT warn level
TON_RISE	0x61	0xE02B	2.6875 ms	2.6875	Soft-start time
<b>TPS544C20</b>					
IOUT_CAL_GAIN	0x38	0x8821	1.0071 mΩ	1.0071	DCR of output inductor
IOUT_CAL_OFFSET	0x39	0xE000	0.0000 A	0	Current offset for GUI readout
IOUT_OC_FAULT_LIMIT	0x46	0xF832	25.0 A	25	OC fault level
IOUT_OC_FAULT_RESPONSE	0x47	0x3C	Restart continuously		Response to OC fault
IOUT_OC_WARN_LIMIT	0x4A	0xF828	20.0 A	20	OC warning level
MFR_04 (VREF_TRIM)	0xD4	0x0000	0.000 V	0	Trim voltage
ON_OFF_CONFIG	0x02	0x02	Mode: always converting		Control signal and operation command not required
OPERATION	0x01	0x00	Unit: immediate off; margin: none		Response to turn off trigger
OT_FAULT_LIMIT	0x4F	0x007D	125°C	125	OT fault level
OT_WARN_LIMIT	0x51	0x0064	100°C	100	OT warn level
TON_RISE	0x61	0xE02B	2.6875 ms	2.6875	Soft-start time

If it is desired to configure the EVM to settings other than the factory settings shown in [Table 5-1](#), the TI Fusion Digital Power Designer software can be used for reconfiguration. It is necessary to have input voltage applied to the EVM prior to launching the software so that the TPS544B20 or TPS544C20 installed is active and able to respond to the GUI and the GUI can recognize the device. The default configuration for the EVM is to start converting at an input voltage of 4.5 V; therefore, to avoid any converter activity during configuration, an input voltage less than 4.5 V must be applied. An input voltage of 4 V is recommended.

### 5.1 Configuration Procedure

1. Adjust the input supply to provide 4 V<sub>DC</sub>, current limited to 1 A.
2. Apply the input voltage to the EVM. See [Figure 4-1](#) and [Figure 4-2](#) for connections and test setup.
3. Launch the Fusion GUI software. See the screen shots in [Section 8](#) for more information.
4. Configure the EVM operating parameters as desired.

## 6 Test Procedure

### 6.1 Line/Load Regulation and Efficiency Measurement Procedure

1. Set up the EVM as described in [Section 4.3](#) and [Figure 4-1](#).
2. Ensure that the electronic load is set to draw 0 A<sub>DC</sub>.
3. Increase V<sub>IN</sub> from 0 V to 12 V using the DMM to measure input voltage.
4. Use the other DMM to measure output voltage V<sub>OUT</sub>.
5. Vary the load from 0 A<sub>DC</sub> to maximum rated output A<sub>DC</sub> (TPS544B20 = 20 A, TPS544C20 = 30 A). V<sub>OUT</sub> must remain in regulation as defined in [Table 2-1](#).
6. Vary V<sub>IN</sub> from 8 V to 14 V. V<sub>OUT</sub> must remain in regulation as defined in [Table 2-1](#).
7. Decrease the load to 0 A.
8. Decrease V<sub>IN</sub> to 0 V.

### 6.2 Efficiency

To measure the efficiency of the power train on the EVM, it is important to measure the voltages at the correct location. This is necessary because otherwise the measurements will include losses in efficiency that are not related to the power train itself. Losses incurred by the voltage drop in the copper traces and in the input and output connectors are not related to the efficiency of the power train, and they must not be included in efficiency measurements.

**Table 6-1. List of Test Points for Efficiency Measurements**

TEST POINT	NODE NAME	DESCRIPTION
TP8	VIN	Measurement point for VIN +VE
TP9	PGND	Measurement point for VIN -VE
TP7	VOUT	Measurement point for VOUT +VE
TP11	PGND	Measurement point for VOUT -VE

Input current can be measured at any point in the input wires, and output current can be measured anywhere in the output wires of the output being measured. Using these measurement points result in efficiency measurements that do not include losses due to the connectors and PCB traces.

### 6.3 Equipment Shutdown

1. Reduce the load current on both outputs to 0 A.
2. Reduce input voltage to 0 V.
3. Shut down the external fan if in use.
4. Shut down equipment.

## 7 Performance Data and Typical Characteristic Curves

Figure 7-1 through Figure 7-9 present typical performance curves for the PWR-634EVM.

### 7.1 Efficiency




Figure 7-1. Efficiency of 1-V Output vs Line and Load

### 7.2 Load Regulation





Figure 7-2. Load Regulation of 1-V Output


### 7.3 Transient Response



Load Step 10A to 20A

Ch1 = VOUT1 at 50-mV/division, Ch2 = IOUT1 at 5-A/division

**Figure 7-3. Transient Response of 1-V Output at 12 V<sub>IN</sub>, Transient is 10 A to 20 A**




Load Release 20A to 10A

Ch1 = VOUT1 at 50-mV/division, Ch2 = IOUT1 at 5-A/division

**Figure 7-4. Transient Response of 1-V Output at 12 V<sub>IN</sub>, Transient is 20 A to 10 A**


## 7.4 Output Ripple



DC Ripple 1A Load

Ch1 = V<sub>OUT</sub>1 at 20-mV/division, Ch2 = SW Node at 10-V/division


**Figure 7-5. Output Ripple and SW Node of 1-V Output at 12 V<sub>IN</sub>, 1-A Output**



DC Ripple 20A Load


Ch1 = V<sub>OUT</sub>1 at 20-mV/division, Ch2 = SW Node at 10-V/division

**Figure 7-6. Output Ripple and SW Node of 1-V Output at 12 V<sub>IN</sub>, 20-A Output**




Ch1 = VOUT2 at 20-mV/division, Ch2 = SW Node at 10-V/division

**Figure 7-7. Start up from Control 1-V Output at 12 V<sub>IN</sub>, 20-A Output**



Ch1 = VOUT2 at 20-mV/division, Ch2 = SW Node at 10-V/division

**Figure 7-8. Shutdown from Control and SW Node of 1-V Output at 12 V<sub>IN</sub>, 20-A Output**



50% PreBias Start No Load

**Figure 7-9. 50% PreBias Start (No Load)**

## 8 Screen Shots

### 8.1 Fusion GUI Screen Shots




Figure 8-1. First Window at Fusion Launch



Figure 8-2. Scan Finds Device Successfully




Figure 8-3. Software Launch Continued



Figure 8-4. Software Launch Continued

Use this next screen to configure the following (Figure 8-5):

- OC fault and OC warn
- OT fault and OT warn
- Power good limits
- Fault response
- UVLO
- On/Off configuration
- Soft-start time
- Margin voltage




**Figure 8-5. First Screen After Successful Launch: Configure- Limits & On/Off**

**Screen Shots**


Use this screen to configure the following (Figure 8-6) :

- $V_{REF}$  trim
- $I_{OUT}$  cal gain (DCR of output choke)




**Figure 8-6. Configure – Other**

Use this screen to configure all of the configurable parameters (Figure 8-7). The screen also shows other details, like hexadecimal (hex) encoding.




**Figure 8-7. Configure – All**

Changing the on/off configuration prompts a pop-up window with details of the options **Figure 8-8**.



**Figure 8-8. Configure- Limits and On/Off- On/Off Configuration Pop-up**


After a change is selected, an orange **U** icon is displayed to offer the *Undo Change* option. The change is not retained until either *Write to Hardware* or *Store User Defaults* is selected. When *Write to Hardware* is selected, the change is committed to volatile memory and defaults back to the previous setting on the input power cycle. When *Store User Defaults* is selected, the change is committed to the nonvolatile memory and becomes the new default (Figure 8-9).



**Figure 8-9. Configure- Limits and On/Off- On/Off Config Pop-up**


## Screen Shots

The  $I_{OUT}$  cal gain can be typed in or scrolled to a new value. The range for  $I_{OUT}$  cal gain is 0.244 m $\Omega$  to 15.5 m $\Omega$  and the resolution step is 30.5  $\mu\Omega$ . If a value is typed in that is between the available discrete steps, the typed-in value does not change but the nearest discrete step is retained. The actual step is displayed on relaunch of the Fusion GUI (Figure 8-10).




**Figure 8-10. Configure- Other-  $I_{OUT}$  Cal Gain Change**

The On/Off configuration can also be configured from the All configuration screens, where the same process applies (Figure 8-11).




**Figure 8-11. Configure- All Config- On/Off Config Pop-up**

After making changes to one or more configurable parameters, the changes can be committed to nonvolatile memory by selecting *Store User Defaults*. This action prompts a *confirm selection* pop-up, and if confirmed, the changes are committed to nonvolatile memory (Figure 8-12).



**Figure 8-12. Configure- Store User Defaults**

In the lower left corner, the different view screens can be changed. The view screens can be changed between *Configure*, *Monitor* and *Status* as needed (Figure 8-13).




**Figure 8-13. Change View Screen to Monitor Screen**

## Screen Shots

When the *Monitor* screen is selected (Figure 8-14), the screen changes to display real-time data of the parameters that are measured by the controller. This screen provides access to:


- Graphs of  $V_{OUT}$ ,  $I_{OUT}$ , Temperature, and  $P_{OUT}$ . As shown,  $P_{OUT}$  display is turned off.
- *Start/Stop polling* which turns on or off the real-time display of data.
- Quick access to on/off configuration
- Control pin activation, and operation command. As shown, because the device is configured for *always converting*, these radio buttons are either grayed-out or have no effect.
- Margin control
- PMBus log, which displays activity on the PMBus
- *Tips and hints*, which displays additional information when the cursor is hovered over configurable parameters.

At first GUI launch, faults can occur due to communications during power up. These faults can be cleared once the device is enabled.




**Figure 8-14. Monitor Screen**

Selecting *System Dashboard* from the mid-left screen adds a new window which displays system-level information (Figure 8-15).



**Figure 8-15. System Dashboard**

When the EVM starts converting power, the  $V_{OUT}$  graph changes scale to display both the zero and  $V_{OUT}$  level. Once the EVM is converting and clear of any faults, selecting *Clear Faults* clears any prior fault flags (Figure 8-16).



**Figure 8-16. Display Change on Power Up**


## Screen Shots

Selecting *Clear Faults* clears any prior fault flags. Scrolling time window of  $V_{OUT}$  will still show any turn-on event (Figure 8-17).




**Figure 8-17. Faults Cleared**

Selecting *Status* from lower left corner shows the status of the controller (Figure 8-18).




**Figure 8-18. Status Screen**

Selecting the pulldown menu *File- Import Project* from the upper left menu bar can be used to configure all parameters in the device at once with a desired configuration, or even revert back to a *known-good* configuration. This action results in a browse-type sequence where the desired configuration file can be located and loaded (Figure 8-19).



**Figure 8-19. Import Project / Import Configuration File**


Selecting *Store User Configuration to Flash Memory* from the device pulldown menu has the same functionality as the *Store User Defaults* button from within the configure screen. It results in committing the current configuration to nonvolatile memory (Figure 8-20).



**Figure 8-20. Store Configuration To Memory**


**Screen Shots**

Select *Data Logging* (Figure 8-21), from the Tools drop-down menu. This enables logging of common operating values such as  $V_{OUT}$ ,  $I_{OUT}$ , and temperature. The user is prompted to select a location for the file to be stored as well as the type of file. Select the storage location for the file and the type of file. The file will be a CSV file to be stored in the directory path shown. Logging begins when the *Start Data Logging* button is selected, and stops when it is reselected.




**Figure 8-21. Data Logging Details**

Common contents of the data log as shown in (Figure 8-22). The UUT had was running with a modified voltage, at an approximate 3.5-A load and room temperature.



**Figure 8-22. Data Log File**


Selecting *PMBus Logging* (Figure 8-23) from the Tools drop-down menu enables the logging of all PMBus activity in the same way as the datalogging. This includes communications traffic for each polling loop between the GUI and the device. It also includes common operating values such as  $V_{OUT}$ ,  $I_{OUT}$ , and temperature. The user is prompted to select a location for the file to be stored. See the next screen (Figure 8-24).



**Figure 8-23. PMBus Logging**


**Screen Shots**

Select the storage location for the file and the type of file. As shown (Figure 8-24), the file is a CSV file to be stored in the directory path shown. Logging begins when the *Start Logging* button is selected, and stops when it is reselected (as *Stop Logging*). This file can rapidly grow in size, so caution is advised when using this function.



**Figure 8-24. PMBus Log Details**


Data is stored in a CSV file, with a date-stamp name (Figure 8-25).




**Figure 8-25. PMBus Log**

## 9 EVM Assembly Drawing and PCB Layout


Figure 9-1 through Figure 9-5 show the design of the PWR-634EVM printed-circuit board (PCB).




**Figure 9-1. PWR-634EVM Top Layer Assembly Drawing (Top View)**




**Figure 9-2. PWR-634EVM Top Copper**




**Figure 9-3. PWR-634EVM Layer 1 (Top View)**




**Figure 9-4. PWR-634EVM Layer 2 (Top View)**




**Figure 9-5. PWR-634EVM Layer 3 (Top View)**



**Figure 9-6. PWR-634EVM Layer 4 (Top View)**



**Figure 9-7. PWR-634EVM Bottom Copper (Top X-ray View)**



**Figure 9-8. PWR-634EVM Bottom Assembly (Top X-ray View)**

## 10 List of Materials

Table 10-1 lists the EVM components list according to Figure 3-1.

---

### Note

The TPS544C20 version is used for this example.

---

**Table 10-1. PWR091 List of Materials**

DES	QTY	DESCRIPTION	PART NUMBER	MANUFACTURER
C2, C17, C21	3	Capacitor, ceramic, 1000 pF, 50 V, ±10%, X7R, 0402	C1005X7R1H102K	TDK
C4	1	Capacitor, ceramic, 0.01 µF, 25 V, ±10%, X7R, 0402	C1005X7R1E103K	TDK
C5	1	Capacitor, ceramic, 4.7 µF, 16 V, ±10%, X5R, 0603	GRM188R61C475KAA J	MuRata
C6	1	Capacitor, ceramic, 4.7 µF, 10 V, ±20%, X5R, 0402	GRM155R61A475M	MuRata
C7	1	Capacitor, ceramic, 0.1 µF, 10 V, ±10%, X5R, 0402	GRM155R61A104KA0 1D	MuRata
C8, C16	2	Capacitor, ceramic, 0.1 µF, 25 V, ±5%, X7R, 0603	C0603C104J3RACTU	Kemet
C9, C10	2	Capacitor, TA, 560uF, 2 V, +/-10%, 0.005 Ω, SMD	2TPLF560M5	Sanyo
C12, C13, C14, C15	4	Capacitor, ceramic, 10 µF, 25 V, ±10%, X7R, 1206	GRM31CR71E106KA1 2L	MuRata
C18, C19, C24, C25	4	Capacitor, ceramic, 47 µF, 6.3 V, ±20%, X5R, 0805	JMK212BJ476MG-T	Taiyo Yuden
C22, C26	2	Capacitor, ceramic, 1 µF, 25 V, ±10%, X5R, 0402	C1005X5R1E105K050 BC	TDK
C23	1	Capacitor, aluminum, 470 µF, 16 V, ±20%, Ω, SMD	EMVA160ADA471MH A0G	Nippon Chemi-Con
C1, C3	0	Capacitor, ceramic, 0.01 µF, 25 V, ±10%, X7R, 0402	C1005X7R1E103K	TDK
C11	0	Capacitor, ceramic, 1000 pF, 50 V, ±10%, X7R, 0402	C1005X7R1H102K	TDK
C20	1	Capacitor, ceramic, 120 pF, 50 V, ±5%, C0G/NP0, 0402	C1005C0G1H121J	TDK
C27	0	Capacitor, ceramic, 1000 pF, 50 V, ±10%, X7R, 0402	C1005X7R1H102K	TDK
C28	1	Capacitor, ceramic, 33 pF, 50 V, ±10%, C0G, 0402	C1005X7R1H330K	TDK
FID1, FID2, FID3	0	Fiducial mark. There is nothing to buy or mount.	N/A	N/A
H1, H2, H3, H4	4	Bumpon, hemisphere, 0.44 × 0.20, clear	SJ-5303 (CLEAR)	3M
J1	1	Header (shrouded), 100 mil, 5 × 2, gold, TH	5103308-1	TE Connectivity
J2, J3, J4	3	Terminal block 5.08 mm vert 2 pos	ED120/2DS	On-Shore Technology
L1	1	Inductor, Shielded, Composite, 400 nH, 36.8A, 0.0004 Ω, SMD	XAL1060-401MEB	Coilcraft
LBL1	1	Thermal transfer printable labels, 0.650" W x 0.200" H - 10,000 per roll	THT-14-423-10	Brady
!PCB	1	Printed circuit board	PWR634	Any
Q1	1	Transistor, NPN, 40 V, 0.2 A, SOT-23	MMBT3904	Fairchild Semiconductor

**Table 10-1. PWR091 List of Materials (continued)**

DES	QTY	DESCRIPTION	PART NUMBER	MANUFACTURER
R1, R17	2	Resistor, 100 kΩ, 1%, 0.063 W, 0402	CRCW0402100KFKE D	Vishay-Dale
R3, R10, R14	3	Resistor, 0 Ω, 5%, 0.063 W, 0402	CRCW04020000Z0ED	Vishay-Dale
R6	1	Resistor, 20.0 kΩ, 1%, 0.063 W, 0402	CRCW040220K0FKE D	Vishay-Dale
R13, R15, R18	3	Resistor, 49.9 Ω, 1%, 0.063 W, 0402	CRCW040249R9FKE D	Vishay-Dale
R9	1	Resistor, 30.1 kΩ, 1%, 0.063 W, 0402	CRCW040230K1FKE D	Vishay-Dale
R2, R4	0	Resistor, 20.0 kΩ, 1%, 0.063 W, 0402	CRCW040220K0FKE D	Vishay-Dale
R5	0	Resistor, 0 Ω, 5%, 0.063 W, 0402	CRCW04020000Z0ED	Vishay-Dale
R16	0	Resistor, 1.0 Ω, 5%, 0.25 W, 1206	CRCW12061R00JNEA	Vishay-Dale
R8, R11, R12	3	Resistor, 38.3 kΩ, 1%, 0.063 W, 0402	CRCW040238K3FKE D	Vishay-Dale
TP1, TP2, TP3, TP4, TP5, TP6, TP7, TP8, TP12	11	Test point, miniature, red, TH	5000	Keystone
TP9, TP10, TP11	3	Test point, miniature, black, TH	5001	Keystone
U1	1	TPS544C20 18-V, 30-A PMBus Synchronous Buck Converters, RVF0040A	TPS544C20RVF	Texas Instruments

## 11 Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

<b>Changes from Revision A (June 2014 August 2021) to Revision B ()</b>	<b>Page</b>
• Changed user's guide title.....	<a href="#">2</a>
• Updated the numbering format for tables, figures, and cross-references throughout the document. ....	<a href="#">2</a>
• Edited user's guide for clarity .....	<a href="#">2</a>

<b>Changes from Revision * (May 2014) to Revision A (June 2014)</b>	<b>Page</b>
• Added updated PWR-634EVM Schematic drawings.....	<a href="#">4</a>
• Added updated EVM Assembly Drawings and PCB Layout drawings.....	<a href="#">31</a>
• Changed List of Materials.....	<a href="#">35</a>

## STANDARD TERMS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, and/or documentation which may be provided together or separately (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms set forth herein. User's acceptance of the EVM is expressly subject to the following terms.
  - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms that accompany such Software
  - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
- 2 *Limited Warranty and Related Remedies/Disclaimers:*
  - 2.1 These terms do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
  - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for a nonconforming EVM if (a) the nonconformity was caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI, (b) the nonconformity resulted from User's design, specifications or instructions for such EVMs or improper system design, or (c) User has not paid on time. Testing and other quality control techniques are used to the extent TI deems necessary. TI does not test all parameters of each EVM. User's claims against TI under this Section 2 are void if User fails to notify TI of any apparent defects in the EVMs within ten (10) business days after delivery, or of any hidden defects with ten (10) business days after the defect has been detected.
  - 2.3 TI's sole liability shall be at its option to repair or replace EVMs that fail to conform to the warranty set forth above, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.

### **WARNING**

**Evaluation Kits are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems.**

**User shall operate the Evaluation Kit within TI's recommended guidelines and any applicable legal or environmental requirements as well as reasonable and customary safeguards. Failure to set up and/or operate the Evaluation Kit within TI's recommended guidelines may result in personal injury or death or property damage. Proper set up entails following TI's instructions for electrical ratings of interface circuits such as input, output and electrical loads.**

**NOTE:**

EXPOSURE TO ELECTROSTATIC DISCHARGE (ESD) MAY CAUSE DEGRADATION OR FAILURE OF THE EVALUATION KIT; TI RECOMMENDS STORAGE OF THE EVALUATION KIT IN A PROTECTIVE ESD BAG.

---

### 3 Regulatory Notices:

#### 3.1 United States

##### 3.1.1 Notice applicable to EVMs not FCC-Approved:

**FCC NOTICE:** This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.

##### 3.1.2 For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:

#### CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### FCC Interference Statement for Class A EVM devices

*NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.*

#### FCC Interference Statement for Class B EVM devices

*NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### 3.2 Canada

##### 3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210 or RSS-247

#### Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

#### Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur

#### 3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see [http://www.tij.co.jp/lsds/ti\\_ja/general/eStore/notice\\_01.page](http://www.tij.co.jp/lsds/ti_ja/general/eStore/notice_01.page) 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。  
[http://www.tij.co.jp/lsds/ti\\_ja/general/eStore/notice\\_01.page](http://www.tij.co.jp/lsds/ti_ja/general/eStore/notice_01.page)

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required to follow the instructions set forth by Radio Law of Japan, which includes, but is not limited to, the instructions below with respect to EVMs (which for the avoidance of doubt are stated strictly for convenience and should be verified by User):

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないものご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿 6 丁目 24 番 1 号

西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see [http://www.tij.co.jp/lsds/ti\\_ja/general/eStore/notice\\_02.page](http://www.tij.co.jp/lsds/ti_ja/general/eStore/notice_02.page)  
電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。[http://www.tij.co.jp/lsds/ti\\_ja/general/eStore/notice\\_02.page](http://www.tij.co.jp/lsds/ti_ja/general/eStore/notice_02.page)

#### 3.4 European Union

3.4.1 *For EVMs subject to EU Directive 2014/30/EU (Electromagnetic Compatibility Directive):*

This is a class A product intended for use in environments other than domestic environments that are connected to a low-voltage power-supply network that supplies buildings used for domestic purposes. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

---

4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*

6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY MATERIALS PROVIDED WITH THE EVM (INCLUDING, BUT NOT LIMITED TO, REFERENCE DESIGNS AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY EPIDEMIC FAILURE WARRANTY OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.

6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT, REGARDLESS OF WHEN MADE, CONCEIVED OR ACQUIRED.

7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.

8. *Limitations on Damages and Liability:*

8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS OR THE USE OF THE EVMS, REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN TWELVE (12) MONTHS AFTER THE EVENT THAT GAVE RISE TO THE CAUSE OF ACTION HAS OCCURRED.

8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY USE OF AN EVM PROVIDED HEREUNDER, INCLUDING FROM ANY WARRANTY, INDEMNITY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS, EXCEED THE TOTAL AMOUNT PAID TO TI BY USER FOR THE PARTICULAR EVM(S) AT ISSUE DURING THE PRIOR TWELVE (12) MONTHS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.

10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2019, Texas Instruments Incorporated

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (<https://www.ti.com/legal/termsofsale.html>) or other applicable terms available either on [ti.com](https://ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2021, Texas Instruments Incorporated