

**MOUNTING LOCATION:**

Left side of climate control

**TOOLS REQUIRED:**

T-25 Torx Driver

**PARTS INCLUDED:**

(1) S7-1775 mount

**CELL PHONE & MEDIA MOUNT****INSTALLATION INSTRUCTIONS**

**PART#: 75141-404**

**MFG: FREIGHTLINER**

**MODELS & YEARS:**

**Business Class (M2), 2004-2017**

**\*\* ADVISEMENT \*\***

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1:** With the T-25 Torx driver, remove the (4) screws that hold the climate controls in place.

**STEP #2:** Lift up on the left side of the climate control. Place the InDash by PanaVise over the screw holes, under the climate controls. Reinstall the (4) screws.

**INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT**



Prototype installed showing location only



02-12-16