

**MOUNTING LOCATION:**

Multi-Locations

**TOOLS REQUIRED:**

T-25 Torx Driver

**HARDWARE INCLUDED:**

None

**CELL PHONE & MEDIA MOUNT****INSTALLATION INSTRUCTIONS**

**PART#: 75141-508**

**MFG: FREIGHTLINER**

**MODELS & YEARS:**

**Cascadia 125 Evolution 2013-2018**

**Cascadia 126 2008-2017**

**\*\* ADVISEMENT \*\***

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1:** With the T-25 Torx driver, remove ant screws that hold the dash plates in place. You may need to remove more than (1) screw to get the mount in place.

**STEP #2:** Lift up on the dash bezel and place the InDash by PanaVise over the screw hole, and Reinstall the screws.

**INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT**



Prototype installed showing (3) of Many locations



02-06-18