


PART NUMBERS

Table 1

VERTICAL CABLE MANAGEMENT		Mounting Kits (sold separately)	Racks	Doors
Front/Rear	Front Only	WMPVCBE, NRVCB (Center Mount) (Standard mounting for Panduit 2 and 4 post racks. One kit Included.)	R2P Series of Racks R4P Series of Racks ER4P Series of Racks	WMPV Includes Cover
WMPV22E	WMPVF22E			
WMPV45E	WMPVF45E			
WMPVHC45E	WMPVHCF45E			
NRV6	NRVF6	WMPVSMK (Side Mount) (Optional Mounting for 4 post racks and R2PS) (Required Mounting for R2P6S)	R2P Series of Racks R4P Series of Racks	NRD6B1 NRD10B1 NRD12B1
NRV10	NRVF10			
NRV12	NRVF12			

Location Guide for Center Mounting (R2P with WMPVCBE and NRVCB)


Dimensions in () parenthesis are for 6" Vertical Cable Management



Bracket Installation


1

Note:
For additional brackets when installing between two racks use part number **WMPVCBE** or **NRVCB**. Bracket is keyed to be installed in the correct orientation.




Standard Rack Installation

2




Bottom Mounting Location



Rear Bottom Mounting Location

Note:
Arrows and flags must point upward

4



#12-24 Screws

3

Location pin(s)

Top Mounting Location


Installation Instructions R2PS using WMPVSMK side mounting kit

Note: Mount the racks to the floor (with the appropriate space between racks indicated in Table 2.)

Table 2


Part Number	Space
WMPV22E WMPV45E WMPVF22E * WMPVF45E *	5"
NRV6 NRVF6 * WMPVHC45E WMPVHCF45E *	6.75"
NRV10 NRVF10*	10"
NRV12 NRVF12 *	12"

* FOR USE WITH R2P6S




Installation Instructions Required mounting for R2P6S using WMPVSMK side mounting kit

Note: Mount the racks to the floor (with the appropriate space between racks indicated in Table 2.)




Installing Front Only Managers for Front and Back cable management.

Use a front only manager for additional cable management on the back of the rack (see Table 2 for all compatible managers for this rack)




Installation Instructions R4P using WMPVSMK side mounting kit


Note: Mount the racks to the floor (with the appropriate space between racks indicated in Table 2.)



Opening and Closing Cover for WMPV managers




Wire Retainer Installation (WR5E) SOLD SEPERATELY



Opening and Closing Cover for NRV managers


Door Latches

Door Finger Tabs




Installation

Line up finger tabs with door latches. Then squeeze door and fingers together to engage (4 places).



To open, grasp back of door and push top button with thumb. Repeat with bottom button.



To close, grasp cable retainers and door until latched

Top Latch Buttons

Bottom Latch Buttons

Removal

To remove door, press bottom latches first, then press top latch buttons while holding door

For instructions in Local Languages and Technical Support:

www.panduit.com/resources/install_maintain.asp

PANDUIT

www.panduit.com

E-mail:

techsupport@panduit.com

Fax:

(866)405-6654